



HOW TO USE INSTRUCTION GUIDE

DUPLEX DUAL EXTRACT VAPORIZER

PACKAGE FEATURES

- 1000 mAh Variable Voltage Battery
- 4 Temperature Settings
- 4.0V
- **3.8V**
- 3.6V
- 3.4V
- Triger Style Button
- 15sec Pre Heat Option
- Dual Quartz Wax Tank
- Ceramic Glass Oil Tank
- Magnetic Connectors
- USB Charger

HOW TO USE STEP BY STEP INSTRUCTIONS

• 1000mAh ADJUSTABLE BATTERY

CERAMIC GLASS
 OIL TANK





POWER BUTTON

HOW TO TURN ON/OFF ADJUST VARIA

TURN ON:

Press POWER BUTTON 5 times quickly.

TURN OFF

Press POWER BUTTON 5 times quickly.

ADJUST VARIABLE VOLTAGE TO ADJUST VOLTAGE:

POWER BUTTON

Once the **DUPLEX** is **ON**Press **POWER BUTTON**

3 times quickly – • Red Light 4.0V

Press 3 times - Orange Light 3.8V Press 3 times - Green Light 3.6V

Press 3 times - Blue Light 3.4V

55.0mm



POWER BUTTON

PRE-HEAT OPTION

Once the **DUPLEX** is **ON**Press **POWER BUTTON**2 times quickly to begin preheat **15 SECOND PRE HEAT CYCLE**Press **POWER BUTTON** 1 time
to deactivate.



LOADING ESSENTIAL OILS INTO THE CERAMIC GLASS OIL TANK

- 1.) Remove Mouthpiece from the CERAMIC GLASS OIL TANK
- 2.) Load the essential oils on the side walls
- 3.) Place mouthpiece back on.
- 4.) Attach the magnetic adapter onto the cartomizer and place into the

DUPLEX battery.



LOADING EXTRACTS INTO THE DUAL QUARTZ WAX TANK

- 1.) Unscrew the mouthpiece from the DUAL QUARTZ WAX TANK heating chamber
- 2.) Place extracts inside the heating chamber
- 3.) Screw the mouthpiece back onto the heating chamber
- Attach the magnetic adapter onto the concentrate heater and place into

the **DUPLEX** battery.

CHARGING INSTRUCTIONS

- 1.) Attach the DUPLEX USB
 CHARGER into the charging port
 located on the front of the unit
- The USB LED indicator will turn Red during charging and TURN OFF when the charge is complete.

Total charge time around 1 hour.

WARRANTY

One Year Warranty is included with **DUPLEX** purchase.

Warranty **DOES NOT** apply to **DUPLEX** batteries at fault from use of **NON DUPLEX** CHARGER.

If for any reason your **DUPLEX** stops working please contact us to open a claim

To ensure the best experience, please read and understand the instructions fully before your first use of the **DUPLEX**. We strongly recommend these instructions are kept for future reference.





FOR MORE INFO VISIT

WWW.00ZELIFE.COM

110.0mm