

Dr.Dabber® Light™

Instruction Manual



Package Contents

- Light™ Battery
- Light™ Atomizer w/ Mouthpiece
- Loading Tool
- Light™ USB Charger



How to Use

On/Off

- Press the power button 5 times to turn On/Off.

Loading

- Pull the mouthpiece and sleeve off the atomizer to reveal the heating coil and wick of the atomizer.

- Load your product directly onto the wick using the included Loading Tool. It is recommended to load only the amount of product equal to a grain of rice.

- Place the mouthpiece and sleeve back onto the atomizer prior to use.

Operating

- Press and hold the power button to use.

Charging

- Charge the Light by removing the atomizer and screwing on the Light USB Charger. The charger LED will illuminate Red to indicate charging, and Green to indicate fully charged. The LEDs blinking 3 times indicates low battery.

Cleaning

- Light atomizers can be cleaned by submerging the atomizers into 70% isopropyl alcohol for 20-30 minutes. Allow atomizers to completely dry before use.

Atomizers should be replaced when any of the following occurs:

- The wick is dark, crusted or damaged.
- You are experiencing a "burnt" taste.
- The ceramic dish is cracked or broken, or you are experiencing leaking.
- You are experiencing decreased vapor production.



Support

Warranty

- We offer a 1 year warranty on all batteries, chargers, and electrical components. If you have any issues with our products, please contact our Customer Service Department by emailing info@drdabber.com with your order number or your shipping address, full name and description of issue. **All 3rd party purchases will be required to provide proof of purchase.**

Registration

- Register your Dr.Dabber product today to receive helpful tips, faster technical support, and to activate it's warranty.

drdabber.com/register

Safety

- Our products are intended for use by persons of legal age, not by children, women who are pregnant or breastfeeding, or persons with or at risk of heart disease, high blood pressure, hypertension, diabetes, or taking medicine for depression or asthma. Discontinue use and consult a physician if you experience symptoms such as nausea, vomiting, dizziness, diarrhea, weakness, rapid heart-beat or hypertension.

⚠ WARNING: Cancer and Reproductive Harm
www.P65Warnings.ca.gov



Dr.Dabber®

5016 SCHUSTER STREET
LAS VEGAS, NEVADA 89118
DRDABBER.COM