



# FOCUS V

# CARTA

## USER MANUAL

Welcome and thank you for being part of the FOCUS V Family. The FOCUS V CARTA 2 is an amazing device and we want to help you get the full experience. Please take a few minutes to read through this user manual and don't forget to share your experience on social media with #cartagang!

### START UP

To power on the device, press the POWER (O) button five times. Your FOCUS V CARTA 2 will then display the startup animation and load your previous settings. To power down your FOCUS V CARTA 2, press the POWER (O) button five times. The OLED screen will automatically turn off after two minutes of inactivity. Your FOCUS V CARTA 2 will then enter into standby mode. Press any button to wake from standby mode. Your device will automatically power down after ten minutes of inactivity.

Once powered ON the display will show the following indicators:

- 1 Set Temperature
- 2 Current Temperature
- 3 Battery Life
- 4 Timer
- 5 Cycles Count
- 6 Detected Atomizer
- 7 Current Presets Selected

### CONNECTING TO APP

To connect your device to your smartphone via Bluetooth: Scan the code below to find the FOCUS V CARTA app. Download and install the app to your phone. Power on your CARTA 2. Make sure Bluetooth is enabled on your phone and pair to the device labeled CARTA 2. Once the device is paired, start the FOCUS V CARTA APP. The app should search for available devices and prompt you to select the device you wish to connect to. Once connected, the app/device will confirm connection. You may now use the app to control and configure your device.



### TIME & TEMPERATURE SETTINGS

From the home screen of your FOCUS V CARTA 2, you can press the DOWN (-) button to adjust the desired temperature setting. Now you can press the UP (+) or DOWN (-) to adjust the value. The OLED screen will display your setting accordingly as you increase or decrease the temperatures. Confirm the correct selection and let the device return to the home screen to automatically save your settings.

To enter the Time Settings mode, press the UP (+) button from the home screen of your FOCUS V CARTA 2. The OLED screen will display the Time Settings screen, and now you can press the UP (+) or DOWN (-) to adjust the duration of your session's time. Let the device return to the home screen to automatically save your settings.

**TEMPERATURE RANGE**

- HERB  
300°F - 460°F  
MIN - MAX
- CONCENTRATE  
380°F - 620°F  
MIN - MAX

**TEMPERATURE SETTINGS**  
450°F 40s 100%  
450°F

**TIME SETTINGS**  
450°F 40s 100%  
40s

### START YOUR SESSION

After you have set your desired session settings, press the POWER (O) button two times to start your session. Your FOCUS V CARTA 2 will vibrate and the OLED screen will show the atomizer temperature increase. Once at the desired temperature setting, your device will vibrate and the countdown sequence will begin. NOTE: During the countdown sequence, you can double click the POWER (O) button to extend the session by 10 seconds. To cancel your session, press the POWER (O) button once anytime during the countdown sequence.

**SESH SCREEN**  
450°F 40s 100%  
450°F 40s  
✓ READY

**SCREEN LOCK**  
UNLOCKED (Green padlock icon)  
LOCKED (Red padlock icon)

Pressing the POWER (O) button four times will enable the BUTTON LOCK feature, preventing accidental changes to settings. UNLOCK by pressing the power button four times.

### LED AND SESH PRESETS

Your FOCUS V CARTA 2 comes with five default SESH presets as well as a custom user setting. Press and hold the POWER (O) button to show the SESH preset screen. Press the UP (+) or DOWN (-) buttons to cycle between the preset configurations. Preset 0 will apply user settings.

Out of the box, your FOCUS V CARTA 2 has five LED presets available to select from. Press the POWER (O) button three times to show the LED preset screen. Press the UP (+) or DOWN (-) buttons to cycle between the preset LED configurations. The "OFF" setting will turn off all LEDs.

**LED PRESET**  
450°F 240s 100%  
2  
LED PRESET

**SESH PRESET**  
450°F 240s 100%  
1  
SESH PRESET